



**STEPS TO FOLLOW**

1. Fix the Pulleys at the end of the track ( E and B ) , see figure 6. Put the cable around the pulleys , insert in the groove of the wheels.
2. Close the doors and adjust the cable length, see fig 4.
3. Following the cable length adjustment , insert the excess cable into the connector as illustrated in the fig 4 and then tighten it up with allen key and socket screw ( F ) supplied .
4. When you have achieved the hook eye shape with the cable ( F ) block it between washers and plate ( A/1 ) with the help of socket screws. Repeat it for the other side plate A/2 , see fig 6.

