


N-6817 replacement mirrored door roller


To suit Cox series 21 and 22 systems

1.




Open completely, lift up and out.

2.



Lay door on edge & remove screws.

3.



Adjust rollers and strike if necessary.